
ROCKSOLID INDUSTRIAL CRACK AND PATCH

Product Description

ROCKSOLID INDUSTRIAL CRACK AND PATCH product is a heavy duty, fast setting patching material for concrete block, sidewalks, patios, steps and other concrete or masonry surfaces. This product is suitable for interior or exterior applications. Just add water to create a workable, easy to apply mixture with excellent bonding characteristics. This product may be trowel applied over existing concrete surfaces from a feather edge to ½" thickness to refinish the concrete surface. It can be shaved or molded to the required shape.

Product Benefits

- ❖ Used to enhance the appearance of most concrete surfaces containing imperfections
- ❖ Can be applied to concrete floors to level low spots before applying floor coverings such as wood or tile
- ❖ Used to fill honey-comb or bug holes
- ❖ Vertical, Horizontal, and overhead application
- ❖ Just add water to create a workable, easy to apply mixture.
- ❖ Smooth, creamy consistency
- ❖ Low shrinkage
- ❖ For repairs not greater than 1/8" in depth
- ❖ Trowel or float spread to a smooth coat
- ❖ Fast Setting
- ❖ Can Mold/Shave to shape
- ❖ Fix concrete blemishes
- ❖ Repair spalling/Salt Damage

Primary Applications

- ❖ Sidewalks
- ❖ Patios
- ❖ Steps
- ❖ Driveways
- ❖ Exterior Concrete

Temperature

50°F - 100°F (10°C - 38°C)

Keep Product From Freezing- Do not store in Temperatures lower than 50 F.

Shelf Life and Storage

Twelve months in factory delivered unopened buckets. Keep away from extreme heat, cold and moisture. Maintain at a proper storage temperature of 40-90° F. Keep out of direct sunlight.

Surface Preparation

All surfaces must be structurally sound and non-flexing.

Remove all dust, waxes, sealers, old adhesive residue, curing compounds, oil or other foreign materials prior to application.

It is recommended to abrade and pre-wet the surface before applying the product to a saturated surface dry condition. (NO STANDING WATER)

Application Information

- ❖ Tear bag open at side notches to break the seal. Open the zip pouch
- ❖ Add 10oz of clean water to 3lb bag.
- ❖ Squeeze pouch to remove excess air.
- ❖ Zip pouch closed and knead bag for about 3 minutes until a lump-free consistency is achieved
- ❖ If needed, add up to an additional 6 oz of clean water.
- ❖ Prior to placing the material, dampen or mist the area to be repaired.
- ❖ Product will become stiff in approximately 8-10 minutes, so mix only what you plan on using in this time period.
- ❖ Use a trowel to shape the material to the surrounding surface.

Precautions

Keep out of reach of children and animals. Do not take internally.

Warranty

The technical data and any other printed information furnished by ROCKSOLID are

true and accurate to the best of our knowledge. **ROCKSOLID INDUSTRIAL CRACK AND PATCH** conforms to in house quality control procedures and should be considered free of defects. The data provided is believed to be reliable and is offered solely for evaluation. The use of this product is beyond the control of the seller, therefore the buyer assumes all risks of use and handling whether done in a matter that is in accordance with the provided posted directions or not. ROCKSOLID makes no warranty; expressed or implied, of its products and shall not be liable for indirect or consequential damage in any event.