
ROCKSOLID INDUSTRIAL PUTTY PATCH

Product Description

ROCKSOLID INDUSTRIAL PUTTY PATCH is a fast-setting general purpose cement-based patching material for repairing concrete and masonry. Rocksolid Putty Patch is a proprietary blend of Portland cements, aggregates and additives that achieve initial set in 10-15 minutes, final set in 20-25 minutes. It can be shaved down to achieve a more uniform looking repair after initial set.

Product Benefits

- ❖ Repairs Concrete or masonry
- ❖ Can be shaped, molded and shave down to help form applications
- ❖ Interior and exterior application
- ❖ For repairs greater than 1/8" in depth
- ❖ Trowel or hand application
- ❖ Fast Setting, achieves initial set in 10 minutes and final set in 20-25 minutes – use as a callout/value statement.
- ❖ Can fill holes up to 7" deep in one application
- ❖ Once cured, this is stronger than the concrete being repaired

Primary Applications

- ❖ Driveways
- ❖ Walkways
- ❖ Stairs
- ❖ Patios
- ❖ Pool Decks
- ❖ Basement Floors
- ❖ Garage Floors

Temperature

50°F - 100°F (10°C - 38°C)

Keep Product From Freezing- Do not store in Temperatures lower than 50 F.

Shelf Life and Storage

Twelve months in factory delivered unopened buckets. Keep away from extreme heat, cold and moisture. Maintain at a proper storage temperature of 40-90° F. Keep out of direct sunlight.

Surface Preparation

Prepare the surface by removing any dust, debris, paint, dirt, oil, loose concrete, or any other contaminants that may come in contact with the product. For horizontal patching, it is recommended to abrade the surface by

cutting an approximate 0.75 inch notch to ensure adhesion. Pre-wet the prepared surface before applying the product to a saturated surface dry condition. No standing water, but surface must remain moist during application.

Mixing Instructions

- ❖ 12oz. of potable water per 3 lb bag, never exceeding 14 oz..
- ❖ Pour 12oz. of measured amount of water into the supplied 3lb mixing bag.
- ❖ Thoroughly mix by kneading the material in the bag for no more than 60 seconds to a thick, putty-like consistency.

Application Information

- ❖ Slightly overfill the target repair area with the product
- ❖ Force the product into the saturated surface dry area with a trowel or by hand to secure a complete bond over the whole repair-area surface
- ❖ Allow mixture to set for approximately 8-12 minutes if in a controlled setting. Exterior application, may set up faster than 12 minutes.
- ❖ Shave the material to follow the shape of the surrounding surface following the initial set.
- ❖ Always shave toward the common bonding lines between the repair mortar and the existing surface.

Warranty

The technical data and any other printed information furnished by Rocksolid are true and accurate to the best of our knowledge. **ROCKSOLID INDUSTRIAL CRACK AND PATCH** conforms to in house quality control procedures and should be considered free of defects. The data provided is believed to be

reliable and is offered solely for evaluation. The use of this product is beyond the control of the seller, therefore the buyer assumes all risks of use and handling whether done in a matter that is in accordance with the provided posted directions or not. ROCKSOLID makes no warranty; expressed or implied, of its products and shall not be liable for indirect or consequential damage in any event.